


Congratulations on your purchase of the NEW Xotic Robotalk2! The Robotalk 2 sports two individual envelope filter channels. Each channel is independently voiced and can be preset for different playing style, slow acoustic-like attack, percussive, high speed open-close and many more. Blend each channel together for additional tones or use the internal dip switch to customize your sounds appropriately. There's a switchable input pad for accommodating both active and passive signals.



Internal Dip Switch Setting:


To access the dip switch, remove the bottom plate by unscrewing the 4 screws.

For medium

power P.U.

over 16kdc

coil resistance



*All dip switch may be set at "up" position for bass guitar

Sample Sound Settings:

Default:

For low power P.U.

single coil &

vintage type PAF

Dual Sound Filter

For active

P.U. and preamp


equipped guitar &

bass guitar



Low peak filter: B channel only High peak filter: A channel only

Envelope Phaser



A+B channel

Input impedance (selectable): 1M or 10K ohm

Output impedance: 1K ohm Max current draw: 20mA Dimensions: W4.62" D3.65" H2"

Weight: 0.9 lbs

9V Battery: Alkaline recommended, 20-hours with nominal use Optional external power supply: 9 volt DC (regulated recommended) 2.1mm x 5.5mm standard barrel with negative tip (center)

such as Boss PSA, Ibanez AC109, Dunlop Power brick, Voodoo Labs

Power-all, 1-spot, etc